

DISPLAY SCREEN



FLUSHING STATUS BAR INDICATES "ON" STATUS FOR COLD/REFRIGERATION & HOT/HEATER

Rotate To Select



Press To Dispense

CONTROL KNOB

Water Options



Ambient

Ambient Water:

Rotate Outer Ring of Control Knob to Green Ambient Icon (Room Temperature) and then Press Center Dispense Button.



Sparkling

Sparkling Water:

Rotate Outer ring of Control Knob to Purple Sparkling Icon and then Press Center Dispense Button.



Cold

Cold Water:

Rotate Outer Ring of Control Knob to Blue Cold Icon and then Press Center Dispense Button.



Hot

Hot Water:

Rotate Outer Ring of Control Knob to Orange Hot Icon and then Press Center Dispense Button.



Extra Hot

Extra Hot Water

Rotate Control Knob to Red Extra Hot Icon and Press Dispense Button to Activate the Extra Hot Cycle. Status will be displayed below Extra Hot Icon.

Ready Status indicates Hot Tank has reached Extra Hot Set Point Temperature.

Rotate Outer Ring of Control Knob to Orange Hot Icon and then Press Dispense Button to Dispense Extra Hot Water.



NOTE: Product selection will default back to cold after 5 seconds of inactivity as a safety feature. There is a 2 second delay before dispensing all products to allow for purification and hot safety. Always hold the dispense button to dispense water and release to stop output.